



GENERAL INSTRUCTIONS FOR THE USE OF RECREATIONAL INFLATABLES PAINTBALL PRODUCTS



Please follow these instructions before use and retain for future reference

ALWAYS ensure that all Players, Spectators, and Judges ALWAYS wear ASTM approved Mask & Goggle systems, made specifically for Paintball.

ALWAYS adjust all Paintball markers to shoot at velocities below 300 feet per second,

ALWAYS Use a chronograph to measure the paintball's speed.

ALWAYS follow National, State, Provincial, and Local laws and zoning ordinances.

INFLATING

Locate the Fill/Release valve on each bunker.

Unscrew the upper knob and take off the plug of the valve and inflate the bunker but using the pump. After fully inflating, replace the plug and seal the valve by screwing in the upper knob.

Only use suitable pumps for the valve as they could otherwise be damaged.

Do not use compressed air. DO NOT OVER INFLATE !!! Bunkers work best when slightly under-inflated or soft, so that they will absorb paintball hits instead of bouncing them away. Leave the bunkers soft enough so that a gentle push with your hand against the bunker will allow your hand to move 5 - 8 inches (12 - 20 cm) into the bunker. If the air temperature increases during the day, be prepared to release air to regain "soft" condition.

Once inflated, make sure that the product does not come in contact with stones, gravel or other sharp objects which could puncture the item

TO ASSEMBLE

Once the bunker is inflated, place the Bunker in the desired location on the field. Find a suitable place for the item, making sure it is free from stones and sharp objects.

Before anchoring the bunker to the ground make sure the valve is facing away from the opposing flag station. This way the valve will not be shot, and will remain clean and free of debris.

Once the bunker is placed correctly on the field, anchor the bunkers with the stakes that are provided, using a hammer. Always wear Safety Glasses when using a hammer! Make sure the elastic cord is not "tight", and remains flush against the ground.

Hammer stakes ALL THE WAY INTO THE GROUND! Be sure stakes are hammered so far into the ground so that the head of the stake is BELOW GROUND LEVEL!!

REPAIRING ACCIDENTAL DAMAGE

To repair an accidental puncture, use the included patch kit and follow these simple steps:

Clean the area around the leak with soap and water.

Let dry completely.

Cut a patch from the extra material, (included) about twice the size of the hole.

Apply glue (included) to both the patch and around the hole. Before putting the patch over the hole, let the glue dry until it is tacky, (about 2 or 3 minutes).

Apply patch to the hole, rubbing the bubbles out. Hold in place for about 30 seconds.

CLEAN UP & STORAGE

To deflate, simply open the valve and allow Bunker to deflate. Use mild soap and water to clean the bunkers. AIR dry. Open the valve once the air is out of the bunker, begin to roll it up with the valve open and place in the storage bags. If available use a shop-vac in reverse to remove the excess air from the bunker.

CAUTION!

1/Keep away from sharp, hot and dangerous object

2/Sun can increase the air pressure. If this should happen make sure you let some air out to keep the pressure down.

3/Always use a pump to inflate./ Do not attempt to inflate by mouth. Never place valves in the mouth.

WARNING!

THIS IS NOT A TOY.

MISUSE MAY CAUSE SERIOUS INJURY OR DEATH.

EYE PROTECTION DESIGNED SPECIFICALLY FOR PAINTBALL MUST BE WORN BY USER AND PERSONS WITHIN RANGE.

RECOMMEND 18 YEARS OR OLDER TO PURCHASE.

PERSONS UNDER 18 MUST HAVE ADULT SUPERVISION.

READ OPERATOR'S MANUAL BEFORE USING.

ALWAYS USE A BARREL PLUG TO AVOID INJURIES OR AN ACCIDENTAL MARKER DISCHARGE.

THIS ITEM IS NOT TO BE USED AS A POOL TOY OR LIFESAVING DEVICE!

THIS RECREATIONAL INFLATEABLE AIBALL BUNKER IS NOT FOR USE ON COMMERCIAL PAINTBALL FIELDS.

ANY COMERCIAL USE OF THIS PRODUCT WILL VOID ALL MANUFACTURERS WARRENTIES.

DO NOT OVER INFLATE!!!

DO NOT RETURN TO STORE IF PROBLEM!

Contact : support@supairball.com